

Adding New Manufacturers to WPR / UPR

1. At the WPR computer, close the Wheel Press program.
2. Open Windows Explorer and browse to C:\Program Files\Wheel Shop Automation\Press.
3. Open the file named *WPR4.INI* for the WPR by double clicking on it. For UPR open the file named *UPR4.INI*.
4. Find the section named [Wheel Mfg]
 - a. For Axles use the Section named [Axle Mfg]
 - b. For Gears use the Section named [Gear Mfg]
 - c. For Bearings use the Section named [Bearing Mfg]
5. Add the line: **XX=Manufacturer** as the last line of the section; where XX is the AAR code for the manufacturer and "Manufacturer" is the company's name.
 - a. Example GK=Griffin
6. Select File | Save to save the INI file. Then close the file.
7. Restart the Wheel Press Recorder program.
8. Open the configuration window and scroll until you see the new wheel manufacturer in the list.

Note: If the manufacturer's barcode meets the AAR standard format (<http://www.wheelshopautomation.com/Files/AAR%20Wheel%20Label%20Specification.pdf>) then you will also be able to scan the data into your Wheel Press Recorder.